



Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0



Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0


DRAWINGS ARE TO SCALE




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 2




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 2



Upgrade Units: 0




Upgrade Units: 2




Upgrade Units: 0

DRAWINGS ARE TO SCALE




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 2




Upgrade Units: 2




Upgrade Units: 1




Upgrade Units: 3




Upgrade Units: 0




Upgrade Units: 1




Upgrade Units: 2




Upgrade Units: 1




Upgrade Units: 0




Upgrade Units: 0



Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0


DRAWINGS ARE TO SCALE




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 2




Upgrade Units: 1




Upgrade Units: 1




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 2



Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0


DRAWINGS ARE TO SCALE




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 0




Upgrade Units: 2




Upgrade Units: 2




Upgrade Units: 2









Upgrade Units: 2








Upgrade Units: 2



Upgrade Units: 0




DRAWINGS ARE TO SCALE




EDGE PROFILES (8000 SERIES)

Go West!


Most 8000 series profiles are designed to provide profiles on 441 drawer fronts to match the raised panel profile used in the door. The last three digits of the profile number correspond to the raised panel profile number (i.e. 8641 matches 641). If the last three digits are 800 or higher, there is not a corresponding raised panel profile.




Upgrade Units: 3



Upgrade Units: 3




Upgrade Units: 3




Upgrade Units: 3


DRAWINGS ARE TO SCALE




Upgrade Units: 3



Upgrade Units: 3




Upgrade Units: 3




Upgrade Units: 3

Go West!


(8000 SERIES) EDGE PROFILES




Upgrade Units: 3
Available in 1" Thick Only



Upgrade Units: 3
Available in 1" Thick Only




Upgrade Units: 3
Available in 1" Thick Only




Upgrade Units: 3
Available in 1" Thick Only


DRAWINGS ARE TO SCALE




Upgrade Units: 3
Available in 1" Thick Only



Upgrade Units: 3
Available in 1" Thick Only




Upgrade Units: 3
Available in 1" Thick Only




Upgrade Units: 3
Available in 1" Thick Only

EDGE PROFILES (8000 SERIES)


Go West!




Upgrade Units: 3
Available in 1" Thick Only



Upgrade Units: 3
Available in 1" Thick Only



Upgrade Units: 3
Available in 1" Thick Only



Upgrade Units: 3
Available in 1" Thick Only

DRAWINGS ARE TO SCALE